

OPERATING INSTRUCTIONS

240 Volt Electro Hydraulic Bin Lifter

100kg W.L.L.

WARNING

DO NOT MAINTAIN PRESSURE ON "U"/ARROW BUTTON WHEN CYLINDER IS EXTENDED TO ITS LIMIT AS MOTOR WILL OVERHEAT AND BURNOUT

MAKE SURE BIN LIFTER IS SETUP ON A FLAT FIRM SURFACE:

AVOID USING DURING WINDY CONDITIONS:

STAND UP WIND OF MACHINE WHEN OPERATING:

NEVER OPERATE WITHOUT BIN AND CHAIN UNSECURED:

1. WHEEL BIN LIFTER INTO POSITION & LOCK CASTORS:
2. SECURE BIN LIFTER TO BULK BIN (SKIP) WITH BULK BIN CATCHES:
3. WHEEL BIN INTO POSITION AT FRONT OF BIN LIFTER:
4. LAY BIN BACK SLIGHTLY AS TO RAISE FRONT EDGE OF BASE:
5. PUSH FORWARD & PLACE FRONT EDGE ONTO FOOTPLATE OF SWINGFRAME"
 - Take care that perimeter edge of bin base is behind securing pins:
6. PUSH THE TOP OF THE BIN FORWARD INTO CATCH MECHANISM:
7. SECURE BIN RETAINING CHAIN AROUND FRONT OF BIN:
8. CLIP LATCH LOCK ON CHAIN INTO LOOP ON SWING FRAM:
 - Note that this chain will have some movement to allow for connection of the Self-Lok Hook:
9. OPERATING CONTROLS ARE LOCATED ON THE LEFT HAND SIDE OF BIN LIFTER:
(Isolating Switch & Power Inlet - "Up/Down" Pendant Control)
10. CONNECT POWER SUPPLY (240 Volt AC Single Phase)
11. TURN ISOLATING SWITCH ON:
12. CONFIRM THAT ALL PERSONS ARE CLEAR OF BIN LIFTER:
13. ON THE PENDANT PUSH THE "U" BUTTON TO RAISE THE BIN LIFTER:
(Release Pressure On Button And Machine Will Stop)
14. AGAIN CONFIRM THAT ALL PERSONS ARE CLEAR OF BIN LIFTER:
15. ON THE PENDANT PUSH THE "D" BUTTON TO LOWER THE BIN LIFTER:
16. SUPPORT THE WHEELIE BIN WHEN RELEASING FROM MACHINE:
(Bin Release Lever Situated On Left Side Of Bin Lifter)
17. WHEN FINISHED TURN OFF ISOLATING SWITCH:

STRONGARM MANUFACTURING & SALES P/L

WARRAGUL Vic (03) 5623 3405 0408175069

www.smas.com.au

tim@smas.com.au